

DIVISIO Series – Depaneling Division



ASYS Expands Its Broad Spectrum of Depaneling Systems

ASYS provides a broad product line of depaneling solutions that range from semi-automatic to high-end inline systems. All DIVISIO Series machines utilize the latest linear motor technology and are ergonomically designed with particular focus on reliability, easy operation and reduced footprint.

All systems of the DIVISIO 2000 Series can optionally be equipped with a robot interface. This interface allows the semi-automatic systems to be loaded and unloaded fully automatically:

The **DIVISIO 2000** provides cost-efficient and stressfree depaneling for small batches. The system can therefore be used without any restrictions as a backup for inline production.

The routing axis of the depaneling system **DIVISIO 2100** can be positioned either above or below the electrically driven rotary table.

The **DIVISIO 2300** commands the largest working area within the entire DIVISIO depaneling systems.

The **DIVISIO 3100** is a highly compact depaneling system for cutting single-row panels. The sawing unit/ spindle is mounted on the linear motor driven XY-axis. An optional camera system can be integrated for fiducial recognition and automatic cut inspection.

The **DIVISIO 4000** is an automatic inline system for high volumes and a small product mix. Arriving panels are transferred to a conveyor, lifted and then picked up by the gripper adapter. The cutting module (spindle or saw) is mounted in a fixed position. Different conveyors can be integrated.

With the further development of the **DIVISIO 5100** we have arrived at the 5th generation. The flexible depaneling platform interprets its own status and can be adapted to any requirement: with manual removal, as an inline system, connected to final assembly or as a fully autonomous production island. Smart interfaces automatically initiate the resulting faster product changeover. Numerous functions such as needsbased maintenance cycles, automatic setup changeover, reduced cycle time, digital copy for offline programming or camera systems enable 70% faster setup. As a result, you can produce up to 150,000 more parts per year with the system. You also increase production time by 4 hours to 20.5 shifts per week - uninterrupted and fully autonomous.

The **DIVISIO 6000** is a high dynamic depaneling system for maximum throughput rates. In addition to the high throughput, a modular system enables the integration of final assembly processes. The modular design provides a wide range of freedom. The functional areas for 'depaneling' and 'feeding to follow-up process' are supplemented with a new, additional functional area which enables simple adaptation to speed or process applications.

There for You – Our Service-team!

> worldwide service network & maintenance service



Visit our website. www.asys-group.com





> motivated 24-hour service hotline> highly qualified short response times

> dedicated operator and process training



DIVISIO_Brochure_230404_CC_E

			DIVISIO 2000	DIVISIO 2100	DIVISIO 2300	DIVISIO 3100	DIVISIO 4000	DIVISIO 5100	DIVISIO 6000
Technical	PCB Panel (max. LxW in mm) ¹		460×360	460×460	720×500	360×330	460x350	460×460	460×460
	Machine dimensions (LxWxH in mm) ¹		1320×1970 ×1480	1620×2270 ×1480	1880x2796 x1522	1000×1600 ×1580	1300×1940 ×1760	1200×2360 ×2152	costomized
	Routing	from above	×	×	×	×			
		from below		0			×	×	×
	Sawing from above from below			0		0	0		
	NC-Axes		X/Y/Z	X/Y/Z	X/Y/Z	X/Y/Z	X/Y/Z	X/Y/Z	X/Y/Z
	Handling Axes							1x Carbon	2x Carbon
	Spindle 500 W		0	0	0	0	0	×	0
	Length / Diameter check		x / x	x / x	x / x	x / x		≭/○	x / x
	Lifetime monitoring		×	×	×	×	×	×	×
	Different cutting hights		×	×	×	×	×	×	×
Jnii	Breakage control		×	×	×	×	×	×	×
յ ն	Tool management		×	×	×	×	×	×	×
Routii	Router bit monitoring	length	×	×	×	×		×	×
		diameter	×	×	×	×		×	×
	Router bit dispos	al	0	0	0		0	*	0
		2-up / 8-up mag	*/0	*/0	*/0	*/0		- /¥	
	Auto router exchange with	14-up / 20-up mag	~10	••••	~/0	~/0	*/-	0/0	¥/-
		Manual		0			••1-	0,0	••• <i>1</i>
g Unit	Adjust saw, 0° or 90°	Auto ²							
	Auto			0		0	^		
vin				0		0	0		
Sa	Quick changeover system ³			0					
	ADA / ADA coding			0					
			0/0	0/0	0/0			0/0	0/0
ools								0/0	0/0
ř								0	0
							○/★		
ESD Setup			0	0	0		0	0	0
	ASYCam		0	0	0	0	0	0	0
	Setup by tablet		0	0	0	0	0	0	×
	spindle/protecting cover/ coating/panes/ionisation		×	×	×	×	×	×	×
u	Fiducial recognition		0	0	0	0	0	×	0
	VPC / VTS		0/0	0/0	0/0	0/0		0/0	0/0
/isio	"Bad" mark recognition		0	0	0	0	0	0	0
· MES V	Autom. cut inspection		0	0	0	0	0	0	0
	Code Read		0	0	0	0	0	0	0
	Hand-scanner / Automatic scanner		0/0	0/0	0/0	0/0	0/0	0/0	0/0
	"Good/bad" interface		0	0	0	0	0	0	0
B	MES Interface		0	0	0	0	0	0	0
Δ	Traceability function		0	0	0	0	0	0	0
Output	Segment conveyor					×	0	0	0
	Flat belt						0	0	0
	Carrier transport					0	0	0	0
	Tray Transport							0	0
	Shuttle / Shuttle with cleaning							×	×
Access	Sliding cover		×	×	×	×	×	0	×
	Safety light curtain		0	0	0				
	Technical availab. ≥ 98%		×	×	×	×	×	×	×
Quality	CE declaration		×	×	×	×	×	×	×
	MCT / PCT		× /O	X /O	× /O	× /O	× /O	× /O	≭/○
	Sound pressure test		0	0	0	0	0	0	0
	Stress tests		0	0	0	0	0	0	0
	MSA		0	0	0	0	0	0	0
	Additional cleaning		0	0	0		0		

🗙 Standard \bigcirc Option

Other dimensions on request
Working area saw 460x360 mm
Saw/Router

ADA = Product-specific adapter ADF = Product-specific gripper fingers ADG = Gripper adapter VPC = Visual program correction

VTS = Visual teach system MCT = Machine capability test PCT = Process capability test MSA = Measuring system analysis

Subject to change without notice. Some general descriptions and performance characteristics may not be applicable to all products. Technical specifications are subject to change without notice. Only features and technical data provided in purchasing contract are legally binding. Printed in Germany